



Cordless DECT/GAP telephone with digital answering machine

DCT557x

Operating Instructions

Unpacking your phone

In the box you will find:

- the cordless handset (two handsets with a Twin system, three with a Triple system and four with a Quad system).

- the base unit
- two rechargeable battery cells for each handset.
- a battery compartment cover for each handset.
- a telephone line cable for the base unit.
- a mains power adapter for the base unit.

- charger pods, each with a power adapter, for multihandset system.
- an operating instruction

** Keep your sales receipt as it is your guarantee.


Charging batteries for the first time

Before you start to use your telephone make sure that all batteries are fully charged for 16 hours.

Important note:

This telephone is not designed for Emergency calls when the mains power fails. For Emergency calls you should have a basic phone that operates without mains power, connected to your line so that you can make calls during a power failure.

Phone Function Keys



E TALK / SPEAKER

- Make or accept a call

F DELETE / INTERCOM

- Press to delete the last number or letter entered.
- Press to initiate an intercom call or transfer a call.

G 7 TONE/KEYLOCK Button

- Long press to activate or deactivate key lock

H MENU/OK/MUTE Button

- Press to show menu.
- Press to select an item, or to save an entry or setting.
- Press to mute a call, press again to resume conversation.

I END Button

- During a call, press to hang up.
- During programming, press to cancel and exit without making changes.
- Press and hold to turn the handset on or off.

J PHONEBOOK Button

- Press to access the phonebook.

K REDIAL Button

- Press to review redial list.

L #/PAUSE/RINGER OFF Button

- Press and hold to turn the ringer off.
- Press and hold to add a dialing pause when dialing or entering numbers into phonebook.

A Earpiece

B LC Display

C R Button


- Flash the line
- Access the message playback when in idle mode

D Navigation Button

- Up to increase volume or view the Call log
- Down to decrease volume.

Answering machine operation

The base unit and charger pod(s) should be placed on a level surface. Answering machine controls:



A PAGE Button

- Press to page all system handsets

B Answer ON/OFF

- Press to turn the answering system on or off

C DND (Do Not Disturb)

- Press to turn DND mode on or off

D Up/Down Button

- Press to increase/decrease the telephone base ringer volume when in idle mode
- Press to increase/decrease the volume during playback or call screening

E Message window

- Displays the number of messages
- Displays the message number during playback

F Delete Button

- Delete message

G Skip Button

- Skip to next message

H Play/Stop Button

- Play/Stop message

I Repeat Button

- Go back to previous message or repeat current message

LCD display items



	- Displays when the telephone base is within reception range. - Flashes when the telephone base is out of range
	- Displays when there is a new voice mail message. Available only if you have subscribed to voice mail service from your telephone service provider.)
	- Displays when there are new calls
	- Displays when answering system is on. - Flashes when there are new messages.
	- Scrolls to indicate battery charging when handset is in the telephone base or charger. - Flashes and empty when battery level is low
	- Speakerphone is in use
	- Displays when the ringer is turned off
	- Displays when the alarm is set.
	- Energy saving mode is activated

Introduction

CAUTION: When using telephone equipment, there are basic safety instructions that should always be followed. Refer to the Important safety instructions section in this user's guide for more information.

IMPORTANT: Since cordless phones operate on electricity, you are suggested to have at least one phone in your home that is not cordless, in case of power outage.

Important Installation Guidelines

Avoid sources of noise and heat, such as motors, fluorescent lighting, microwave ovens, heating appliances and direct sunlight.

Avoid areas of excessive dust, moisture and low temperature.

Avoid other cordless telephones or personal computers.

Never install telephone wiring during a lightning storm.

Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.

Never touch non-insulated telephone wires or terminals, unless the telephone line has been disconnected at the network interface.

Use caution when installing or modifying telephone lines.

Telephone base and charger installation

1. Plug the smaller end of the power adapter into the power jack at the bottom of the telephone base.

2. Plug one end of the telephone line into the jack at the bottom of the telephone base.

3. Plug the other end of the telephone line into a telephone wall jack.

4. Plug the larger end of the power adapter into an electrical outlet not controlled by a wall switch. If you have DSL high speed Internet service, a DSL filter is required (not included). Contact your DSL service provider for more information about DSL filter.

CAUTION: Use only the power adaptor that came with this unit. (Telephone base: TENPAO-S003IV0600050 or ESL-IA5060G(6Vdc/500mA), charger: TENPAO-S003IV0600015 or ESL-IA1560G(6Vdc/150mA). Using other power adapters

may damage the unit. Contact your local distributor if you need to order replacement for the power adapters.

Your phone's base station is supplied with an energy-efficient switching power supply (Input 100-240 V_{AC}, Output 6 V_{DC}, 500 mA). The adaptor input power without load is approx. 0.14 W. The average efficiency is approx. 69.12 %.

The electrical consumption of the base is:
- in operation mode (idle/call): approx. 0.75 / 0.9 W
- during charging of the handset: approx. 1.31 W

The charging station(s) supplied with a telephone set is (are) equipped with an energy-efficient switching power supply (Input 100-240 V_{AC}, Output 6 V_{DC}, 150 mA). The zero load is approx. 0.14 W. The average efficiency is approx. 69.14 %.

The charging station has the following power consumption levels:
- without a handset: Approx. 0.14 W
- while charging the handset: Approx. 0.66 W

Telephone jack requirements

To use this phone, you need a RJ11C type modular telephone jack, which might look like the one pictured here, installed in your home. If you do not have a modular jack, call your local phone company to find out how to have one installed.

CAUTION:

1. Use only the power adapter that came with this unit. Using other power adapters may damage the unit.

2. To prevent fire or electrical shock hazard, do not expose this product to rain or moisture.

Battery installation

For optimum battery performance, charge the battery for 16 hours before first use.

1. Make sure the battery compartment cover is not attached with the handset.

2. Insert the AAA rechargeable batteries in the battery compartment, matching the +/- polarity markings.

3. Align the cover against the battery compartment and slide it upwards until it clicks into place.

4. Charge the handset by placing it in the telephone base or charger. The light on the handset is on when charging.

CAUTION:

1. To reduce the risk of fire or personal injury, use only the model (HIGHPOWER - HRF AAA400 or SANIK- SN AAA40H, 400mA 1.2V Ni-MH) which is compatible with this unit.

2. If the handset will not be used for an extended period of time, unplug the batteries and remove them from the handset to prevent possible leakage.

Battery safety - CAUTION

ONLY use the rechargeable batteries supplied with the handset. DO NOT use non-rechargeable batteries - they may explode and cause damage to your telephone.

ECO Mode

Both in Call mode as well as in Standby mode, the radiation is reduced considerably as compared to standard, cordless DECT telephones.



Advanced settings

Dialing mode

To change the dialing mode:

- 1.
2. : ADV SETTING ->
3. : DIAL MODE ->
4. : Select the desired setting ->

Reset

This feature allows you to restore all system settings, except the answering system messages and phonebook, to default settings. This feature could be useful, for example, if you have forgotten the security code to access the answering system remotely.

- 1.
2. : ADV SETTING ->
3. : RESET ->
- 4.

NOTE: All settings under the ANS SYSTEM, BLOCK LIST, PROGRAM DND, CLOCK & ALARM, SETTINGS, HANDSET TONES, BASE TONES and ADV SETTING menus in the handset will be restored to default settings, the redial list and call log will also be cleared.

NOTE: When ENERGY SAVE is turned on, the icon shows on the handset screen.

Recall time

This setting allows you to choose between SHORT, MEDIUM or LONG to accommodate the setting of your telephone service provider for using customer calling service, such as call waiting.

To change the recall time:

- 1.
2. : ADV SETTING ->
3. : RECALL TIME ->
4. : Select the desired setting ->

Registering a handset

The telephone system can support up to a total of 5 cordless handsets. Handsets that were included with your main base are pre-registered.

To add or re-register a handset:

1. Press and hold on the base for 5 seconds until a beep sounds.
2. when handset displays REGISTER YOUR HANDSET.
3. Enter the PIN (default: 0000) ->

A beep sounds on the handset when the registration is successful.

NOTES:

1. An error tone will sound if the registration is not successful.

Deregistering a handset

- 1.
2. : ADV SETTING ->
3. : DEREGISTER ->
4. Enter the PIN (default: 0000) ->
5. : select the desired handset ->

Handset options

Ringer volume

You can set the handset ringer volume from level 1 to level 5 or turn the ringer off.

- 1.
2. : HANDSET TONES ->
3. : RING VOLUME ->
4. : select the desired setting ->

NOTE: Press and hold the key to switch the ringer between on and off when the handset is in idle mode. The icon displays on the screen when ringer off feature is activated.

Ringer melody

You can select from 10 ringer tones.

- 1.
2. : HANDSET TONES ->
3. : RING MELODY ->
4. : select the desired setting ->

Key tone

The handset can be programmed to emit a tone with each key press. To change the key tone setting:

- 1.
2. : HANDSET TONES ->
3. : KEY BEEP ->
4. : ON or OFF ->

Display language

To change the display language:

- 1.
2. : SETTINGS ->
3. : LANGUAGE ->
4. : select the desired setting ->

Equalizer

This feature allows you to change the balance of the audio of the handset to best suit your hearing.

- 1.
2. : SETTINGS ->
3. : EQUALIZER ->
4. : select from NATURAL, BASS or TREBLE.
- 5.

Energy save

This feature enables the handset to operate in energy saving mode. With this feature turned on, the handset will automatically turn the handset backlight off.

- 1.
2. : SETTINGS ->
3. : ENERGY SAVE ->
4. : ON or OFF ->
- 5.

NOTE: When ENERGY SAVE is turned on, the icon shows on the handset screen.

Base options

Base ringer melody

You can select from 5 ringer tones.

- 1.
2. : BASE TONES ->
3. : BASE MELODY ->
4. : select the desired setting ->

Base ringer volume

You can set the telephone base ringer volume from level 1 to level 5 or turn the ringer off.

- 1.
2. : BASE TONES ->
3. : BASE VOLUME ->
4. : select the desired setting (LEVEL 1 to 5 or OFF) ->

Block list

You can program telephone numbers into the block list so that the telephone silences when a call is received from one of the blocked numbers. The handset shows BLOCK LIST when the programmed numbers call and will not record the number in the caller ID history.

To add a new entry

- 1.
2. : BLOCK LIST ->
3. : ALARM -> ADD NEW.
4. Enter the desired number ->

To view the list

- 1.
2. : BLOCK LIST ->
3. to browse through the block list.

To edit an entry

- 1.
2. : BLOCK LIST ->
3. : select the desired entry ->
4. : EDIT CONTACT -> twice.
5. Edit the number by using the key to erase and backspace, then enter new numbers using the dial pad keys and press .

To delete an entry

- 1.
2. : BLOCK LIST ->
3. : select the desired entry ->
4. : DELETE ENTRY -> 3 times to confirm.

To delete all entries

- 1.
2. : BLOCK LIST ->
3. : select any entry ->
4. : DELETE ALL -> twice to confirm.

Do not disturb

When **DO NOT DISTURB (DND)** mode is activated, all incoming calls will be silent. This feature only silences the ringer, the incoming number, if you have subscribed to the caller ID service from your telephone service provider, will be recorded in the caller ID history as normal.

Global DND

When global **DND** is activated, all system handsets and the telephone base will be silent when there is an incoming call. Press the DND button on the telephone base to turn this feature on or off.

Handset DND

You can program individual handset to silence during predetermined time frames. This setting is independent to each handset and only silences the ringer of the handset programmed. To program the DND time for individual handset

- 1.
2. : PROGRAM DND ->
3. : select the desired option ->
4. **ONE TIME:**

